

Continued from page 21:

The play is removed by fitting thin metal washers between fuselage wingroot pins and their metal fitting in the fuselage. The pins are slid out of the fuselage tubes by fitting a steel rod through the hole in the opposite pin, and driving the pin out from the inside with a hammer. It should be possible to drive the pin back into place, after fitting the metal washer, using only a 500 g (1 lb) hammer and a few blows. If it returns too easily, then either knurl the seating area slightly until a tight fit is obtained again, or secure the pin by means of a 4 mm ϕ (1/6 inch) bolt and nut which you have to drill through the fuselage tube and the pin.

During each annual re-inspection as well as after hard landings, crashes or similar incidents, the elevator actuator bellcrank inside the fin has to be inspected in accordance with TN no.21. (This is no longer applicable after the accomplishment of TN no.22, LTA 82-221 !)

Also during each annual re-inspection the spar inside must be inspected thoroughly for penetrated water, discoloration or wood-destroying mould fungi attack in accordance with TN no.23 "Action point 1.1".

2.9 Appendix

3-side view, rigging data	Page 23
Airspeed indicator calibration	Page 24
Lubrication Scheme	Page 25
Elevator levelling template	Page 26
Diagram Empty Weight C.G.	Page 27