Blatt 1 von 1

## **ASK 21** Maintenance Instruction Wheel-Rim Tost Penta, Issue I

Subject: Alternative rim for main wheel

Applicability: ASK 21, TCDS EASA.A.221, variants ASK 21 and ASK21Mi, all serial numbers

**Reason:** The rim Tost Penta 125 – 1<sup>1</sup>/<sub>4</sub>" can be installed instead of the rim specified in the Maintenance Manual (Cleveland 40-78B)

Action: For every rim model there is an appropriate set of space bushings, which are threaded onto the axle on both sides of the wheel. Whenever the rim models are exchanged, the space bushings have to be replaced, too. Furthermore, a tyre tube with short valve must be used. The brake calliper retains unchanged.

Material: For the Tost-rim:

Part no	Pcs	Denomination	
210.21.0027	1	Space bushings for Tost Penta 125-1¼" (Left: I = 37; Right: I = 31)	
210.21.0028	1	Clamp washer for Tost Penta 125-11/4"	
	1	Tyre tube with short valve	

For the Cleveland-rim:

Part no	Pcs	Denomination	
210.21.0005	1	Space bushing left f. main wheel (I = 29)	
210.21.0006	1	Space bushing right f. main wheel $(I = 30)$	
210.21.0007	1	Space ring f. main wheel (Ø35/10 - 10)	
210.21.0008	1	Clamp washer f. main wheel (Ø40/10,1 - 2)	
	1	Tyre tube with short valve	

Notes:

none

Poppenhausen, 01.06.10

## Alexander Schleicher

GmbH & Co.

iA M. Cie

(M. Greiner)